

6

5

4

3

2

1

T34

Neck Position Pickup
EVL-35 NECK


Bridge Position Pickup
EVL-35 BRIDGE

MAIN VOLUME
B500K

BALANCE VOLUME
A500K/C500K

TREBLE
B100K

BASS
B100K



OUTPUT JACK








WHITE

BLACK

RED

BLACK

RED



D

C

B

A

D

C

B

A