

6

5

4

3

2

1

# T35

Neck Position Pickup  
EVL-35-5ST NECK

Bridge Position Pickup  
EVL-35-5ST BRIDGE

MAIN VOLUME  
B500K

BALANCE VOLUME  
A500K/C500K

TREBLE  
B100K

BASS  
B100K

OUTPUT JACK

RED

BLACK

WHITE

BLACK

RED

D

C

B

A

D

C

B

A

